


How do I upgrade the firmware of my M7350?

Suitable for: M7350

There are two methods to upgrade your M7350's firmware, please follow either one of them to upgrade your M7350.

Note: If this is your M7350 first boot in a week and your M7350's firmware version is not latest, there will be a firmware update message in the M7350's screen. (M7350 will automatically detect whether there is a latest firmware version in the cloud server every week)



Method 1: Local upgrading

Step 1

First please download the latest firmware of M7350 from our website. Here is the download link: <http://www.tp-link.com/en/products/details/?categoryid=&model=M7350#down>

Note: The firmware is a zipped file. Please don't unzip it. You will need the whole zipped file to upgrade your M7350.

Step 2

Please connect your computer to M7350 wirelessly or via USB cable (about how to access the M7350's Internet via USB cable, please refer to [FAQ 758](#)), then open the web browser and type the IP address of your M7350 (default is **192.168.0.1** or **http://tplinkmifi.net**) in the address bar. After that, please press Enter.



Step 3

Type the username and password in the login page (default username and password are both **admin**), and log into the management webpage of your M7350.



Step 4

Select **Advanced—>Device—>Firmware Update**, and the webpage will show like below:

TP-LINK

Wizard Status SMS **Advanced** Logout

- Dial-up
- Wireless
- DHCP Server
- Data Settings
- Storage Sharing
- Device**
- Firmware Update**
- Factory Defaults
- Account Management
- Shutdown
- Time Settings

Firmware Update

Firmware Version: 1.0.8 Build 140924 Rel.1005n

Update via the cloud server

Update via the local server

Check for Updates

Update

Step 5

Select "Update via the local server", and click **Browse**.

Firmware Update

Firmware Version: 1.0.8 Build 140924 Rel.1005n

Update via the cloud server


Update via the local server

Browse

Update

Step 6

Select the zipped firmware file of M7350 you have just downloaded from TP-LINK website on your computer, and click **OK**.



Step 7

Click **Upgrade** button to update your M7350's firmware, please wait for a few minutes until upgrading process is completed, and M7350 will reboot automatically.



Method 2: Cloud upgrading

Step 1

Please connect your computer to M7350 wirelessly or via USB cable (about how to access the M7350's Internet via USB cable, please refer to [FAQ 758](#)), then open the web browser and type the IP address of your M7350 (default is **192.168.0.1** or **http://tplinkmifi.net**) into the address bar. After that, please press Enter.



Step 2

Type the username and password in the login page (default username and password are both **admin**), and log into the management webpage of your M7350.



Step 3

Select **Advanced—>Device—>Firmware Update**, and the webpage will show like below:

TP-LINK Wizard Status SMS **Advanced** Logout

Dial-up
Wireless
DHCP Server
Data Settings
Storage Sharing
Device
Firmware Update
Factory Defaults
Account Management
Shutdown
Time Settings

Firmware Update

Firmware Version: 1.0.8 Build 140924 Rel.1005n

Update via the cloud server

Update via the local server

Check for Updates

Update

Step 4

Select **"Update via the cloud server"**.

1. If this is your M7350's first boot in a week, you can see the latest firmware version message directly.

Firmware Update



Firmware Version: 1.0.10 Build 141015 Rel.1009n

Update via the cloud server

Check for Updates

New Version: [1.0.11](#) (2.12MB) [Release Note](#)

Update via the local server

Update

2. If there isn't the latest firmware version message, please click **Check for Updates**.

Firmware Update



Firmware Version: 1.0.8 Build 140924 Rel.1005n

Update via the cloud server

Check for Updates

Update via the local server

Update

Note: Please ensure that your device can access the Internet at this time.

If your M7350's firmware is already the latest, there will be following indication message "**Your current firmware is up to date**". If not, you can find the latest firmware version message, it will show under the "**Check for Updates**" button.

Update via the cloud server

Check for Updates

Your current firmware is up to date.

Step 5

Move your mouse to the New Version and click it, it will download the latest firmware package, then you can choose local upgrading. **(Optional)**




Move your mouse to the Release Note and click it, you can see all the release notes in this firmware.



Note: Here is just a sample of Release note.


Step 6

Click **Upgrade** button to update your M7350's firmware.



It will download the latest firmware from the cloud server firstly.

Note: You can pause download anytime, when you update it again, it will remember your download history and continue to download from the historical record.



When the download is complete, it will automatically begin update, please wait for a few minutes until upgrading process is completed, and M7350 will reboot automatically.

