

# Printer Compatibility List for TL-PS110U/TL-PS110P/TL-WPS510U

Update:2010-07-23

Note: "OK" means the print server is compatible with the printer ;  
 "\ " means the print server is not compatible with the printer;  
 "—" means the function is not tested;

The product only support the **printing function** of the Multi Function Printer.

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
1	HP	Business Ink Jet 1000	OK		OK
2	HP	Business Ink Jet 1100	OK	OK	OK
3	HP	Business Ink Jet cp1700	OK	OK	OK
4	HP	Color LaserJet 1500L	OK		OK
5	HP	Color LaserJet 1600	OK		OK
6	HP	Color LaserJet 2500	OK	OK	OK
7	HP	Color LaserJet 2550	OK	OK	OK
8	HP	Color LaserJet 2550L/LN	OK		OK
9	HP	Color LaserJet 2600	OK		OK
10	HP	Color LaserJet 2600N	OK		OK
11	HP	Color LaserJet 2605	OK	OK	OK
12	HP	Color LaserJet 2700N	OK		OK
13	HP	Color LaserJet 2840	OK		OK
14	HP	Color LaserJet 3550		OK	
15	HP	Color LaserJet 3700	OK	OK	OK
16	HP	Color LaserJet 4000		OK	
17	HP	Color LaserJet 4100		OK	
18	HP	Color LaserJet 4500		OK	
19	HP	Color LaserJet 4650	OK	OK	OK
20	HP	Color LaserJet 8550		OK	
21	HP	Color Laserjet CP1215	OK		OK
22	HP	Color Laserjet CM1312 MFP	OK		OK
23	HP	DesignJet 100	OK	OK	OK
24	HP	DesignJet 500	OK	OK	OK
25	HP	DesignJet 600		OK	
26	HP	DesignJet 650C		OK	
27	HP	DesignJet 700		OK	
28	HP	DesignJet 750C+		OK	
29	HP	DeskJet 1120C		OK	
30	HP	DeskJet 1125C	OK	OK	OK
31	HP	DeskJet 1180C	OK	OK	OK
32	HP	DeskJet 1280	OK	OK	OK
33	HP	DeskJet 2300	OK		OK
34	HP	DeskJet 3325	OK		OK
35	HP	DeskJet 3420	OK		OK
36	HP	DeskJet 3535	OK		OK
37	HP	DeskJet 3650	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
38	HP	DeskJet 3743	OK		OK
39	HP	DeskJet 3745	OK		OK
40	HP	DeskJet 3748	OK		OK
41	HP	DeskJet 3820	OK	OK	OK
42	HP	DeskJet 3920	OK		OK
43	HP	DeskJet 3940	OK		OK
44	HP	DeskJet 400/420		OK	
45	HP	DeskJet 450C	OK	OK	OK
46	HP	DeskJet 500/550C		OK	
47	HP	DeskJet 5440	OK		OK
48	HP	DeskJet 5500		OK	
49	HP	DeskJet 5550	OK	OK	OK
50	HP	DeskJet 5652	OK	OK	OK
51	HP	DeskJet 5740		OK	
52	HP	DeskJet 610C	OK		OK
53	HP	DeskJet 670C		OK	
54	HP	DeskJet 680C		OK	
55	HP	DeskJet 720C		OK	
56	HP	DeskJet 810C	OK	OK	OK
57	HP	DeskJet 830C	OK	OK	OK
58	HP	DeskJet 845C	OK		OK
59	HP	DeskJet 895Cxi	OK	OK	OK
60	HP	DeskJet 920	OK	OK	OK
61	HP	DeskJet 920C		OK	
62	HP	DeskJet 930C		OK	
63	HP	DeskJet 9300	OK	OK	OK
64	HP	DeskJet 948C	OK	OK	OK
65	HP	DeskJet 9600	OK	OK	OK
66	HP	DeskJet 9650	OK	OK	OK
67	HP	DeskJet 970C XI	OK	OK	OK
68	HP	DeskJet 9800	OK	OK	OK
69	HP	DeskJet D1560	OK		OK
70	HP	DeskJet D2360	OK		OK
71	HP	DeskJet D2460	OK		OK
72	HP	DeskJet D2560	OK		OK
73	HP	DeskJet D5560	OK		OK
74	HP	DeskJet F370	OK		OK
75	HP	DeskJet F380	OK		OK
76	HP	DeskJet F4185	OK		OK
77	HP	DeskJet F4280	OK		OK
78	HP	DeskJet F4480	OK		OK
79	HP	LaserJet 1005 MFP	OK		OK
80	HP	LaserJet 1010			OK
81	HP	LaserJet 1022	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
82	HP	LaserJet 1022N	OK		OK
83	HP	LaserJet 1100		OK	
84	HP	LaserJet M1120MFP	OK		OK
85	HP	LaserJet 1160	OK	OK	OK
86	HP	LaserJet 1200	OK	OK	OK
87	HP	LaserJet 1220	OK	OK	OK
88	HP	LaserJet 1300	OK	OK	OK
89	HP	LaserJet 1320	OK	OK	OK
90	HP	LaserJet 2100		OK	
91	HP	LaserJet 2200		OK	
92	HP	LaserJet 2200D	OK	OK	OK
93	HP	LaserJet 2300	OK	OK	OK
94	HP	LaserJet 2410	OK	OK	OK
95	HP	LaserJet 2420	OK	OK	OK
96	HP	LaserJet 2500	OK	OK	OK
97	HP	LaserJet 2550	OK	OK	OK
98	HP	LaserJet 3015	OK	OK	OK
99	HP	LaserJet 3030	OK	OK	OK
100	HP	LaserJet 3050	OK		OK
101	HP	LaserJet 3055	OK		OK
102	HP	LaserJet 3200	OK	OK	OK
103	HP	LaserJet 3330	OK	OK	OK
104	HP	LaserJet 3330MFP	OK	OK	OK
105	HP	LaserJet 3380	OK		OK
106	HP	LaserJet 4+		OK	
107	HP	LaserJet 4000		OK	
108	HP	LaserJet 4050		OK	
109	HP	LaserJet 4100 /4100N		OK	
110	HP	LaserJet 4250	OK	OK	OK
111	HP	LaserJet 4300n	OK	OK	OK
112	HP	LaserJet 4300tn/dtn	OK	OK	OK
113	HP	LaserJet 4500		OK	
114	HP	LaserJet 4650	OK	OK	OK
115	HP	LaserJet 5000	OK	OK	OK
116	HP	LaserJet 5000LE		OK	
117	HP	LaserJet 5100IE/SE		OK	
118	HP	LaserJet 5200	OK	OK	OK
119	HP	LaserJet 5L/si		OK	
120	HP	LaserJet 6P / 6L		OK	
121	HP	LaserJet 8100		OK	
122	HP	LaserJet M1005	OK		OK
123	HP	LaserJet M1005 MFP	OK		OK
124	HP	LaserJet M1120 MFP	OK		OK
125	HP	LaserJet M1319F MFP	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
126	HP	LaserJet P2015	OK		OK
127	HP	OfficeJet J3608	OK		OK
128	HP	OfficeJet 4110	OK		OK
129	HP	OfficeJet 4255	OK		OK
130	HP	OfficeJet 4355	OK		OK
131	HP	OfficeJet 5510	OK		OK
132	HP	OfficeJet 5610	OK		OK
133	HP	OfficeJet J5780	OK		OK
134	HP	OfficeJet 6000	OK		OK
135	HP	OfficeJet 6210	OK		OK
136	HP	OfficeJet 6310	OK		OK
137	HP	OfficeJet 6500	OK		OK
138	HP	Officejet 6610	OK		OK
139	HP	OfficeJet 7000			OK
140	HP	OfficeJet 7210	OK		OK
141	HP	OfficeJet H470b	OK		OK
142	HP	OfficeJet J4580	OK		OK
143	HP	OfficeJet J6480	OK		OK
144	HP	OfficeJet K7100	OK		OK
145	HP	OfficeJet K850	OK	OK	OK
146	HP	OfficeJet Pro K5300	OK		OK
147	HP	OfficeJet Pro K5400dn	OK		OK
148	HP	OfficeJet Pro K550	OK		OK
149	HP	Officejet Pro K8600	OK		OK
150	HP	OfficeJet Pro L7380	OK		OK
151	HP	OfficeJet Pro L7590	OK		OK
152	HP	OfficeJet Pro 8000	OK		OK
153	HP	Officejet Pro 8500W	OK		OK
154	HP	Photosmart 2610	OK		OK
155	HP	Photosmart 3110	OK		OK
156	HP	photosmart 7150	OK		OK
157	HP	photosmart 7200	OK		OK
158	HP	photosmart 7550	OK		OK
159	HP	photosmart 7660	OK		OK
160	HP	photosmart 7830	OK		OK
161	HP	photosmart 7900	OK		OK
162	HP	Photosmart 8200	OK		OK
163	HP	Photosmart Plus B209a	OK		OK
164	HP	Photosmart A310	OK		OK
165	HP	Photosmart A520	OK		OK
166	HP	Photosmart B109a	OK		OK
167	HP	Photosmart C309a	OK		OK
168	HP	Photosmart C3180	OK		OK
169	HP	Photosmart C4180	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
170	HP	Photosmart C4280	OK		OK
171	HP	Photosmart C4385	OK		OK
172	HP	Photosmart C4480	OK		OK
173	HP	Photosmart C4580	OK		OK
174	HP	Photosmart C5180	OK		OK
175	HP	Photosmart C5280	OK		OK
176	HP	Photosmart C5380	OK		OK
177	HP	Photosmart C6180	OK		OK
178	HP	Photosmart C6280	OK		OK
179	HP	Photosmart C6380	OK		OK
180	HP	Photosmart C7180	OK		OK
181	HP	Photosmart C7280	OK		OK
182	HP	Photosmart C8180	OK		OK
183	HP	Photosmart D5160	OK		OK
184	HP	Photosmart D5360	OK		OK
185	HP	Photosmart D5460	OK		OK
186	HP	Photosmart D7160	OK		OK
187	HP	Photosmart D7260	OK		OK
188	HP	Photosmart D7360	OK		OK
189	HP	Photosmart Premium C309g	OK		OK
190	HP	PSC 1210	OK		OK
191	HP	PSC 1315	OK		OK
192	HP	PSC 1350	OK		OK
193	HP	PSC 1410	OK		OK
194	HP	PSC 1510	OK		OK
195	HP	PSC 1610	OK		OK
196	HP	PSC 2210	OK		OK
197	HP	PSC 2310	OK		OK
198	EPSON	Aculaser C1100SE	OK	OK	OK
199	EPSON	Aculaser C1600	OK		OK
200	EPSON	AcuLaser C1900	OK	OK	OK
201	EPSON	AcuLaser C3800	OK		OK
202	EPSON	AcuLaser C3800N	OK		OK
203	EPSON	AcuLaser C9100	OK		OK
204	EPSON	Aculaser M2010DN	OK		OK
205	EPSON	Aculaser M2010D	OK	OK	OK
206	EPSON	B-508DN	OK		OK
207	EPSON	B-518DN	OK		OK
208	EPSON	C750	OK	OK	OK
209	EPSON	CC-500L	OK		OK
210	EPSON	CL-760	OK		OK
211	EPSON	CX2900	OK		OK
212	EPSON	CX 3500	OK		OK
213	EPSON	CX 3700	OK		OK
214	EPSON	CX 3900	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
215	EPSON	CX 4100	OK		OK
216	EPSON	CX 4900	OK		OK
217	EPSON	CX 5500	OK		OK
218	EPSON	CX 5505	OK		OK
219	EPSON	CX 5900	OK		OK
220	EPSON	CX6900F	OK		OK
221	EPSON	CX 8300	OK		OK
222	EPSON	DLQ-3500C		OK	
223	EPSON	E-300L	OK		OK
224	EPSON	E-520	OK		OK
225	EPSON	E-720	OK		OK
226	EPSON	EC-01	OK		OK
227	EPSON	EPL 5700		OK	
228	EPSON	EPL 5800	OK	OK	OK
229	EPSON	EPL 5900	OK	OK	OK
230	EPSON	EPL 6100	OK	OK	OK
231	EPSON	EPL 6200	OK	OK	OK
232	EPSON	EPL 6200L	OK		OK
233	EPSON	EPL N2120		OK	
234	EPSON	LP2500	OK		OK
235	EPSON	LP-7700	OK		OK
236	EPSON	LP-8300		OK	
237	EPSON	LP-8700	OK		OK
238	EPSON	LP-8800C	OK		OK
239	EPSON	LP8900	OK		OK
240	EPSON	LP-9500C	OK		OK
241	EPSON	LQ 100		OK	
242	EPSON	LQ 1000C		OK	
243	EPSON	LQ 1170+		OK	
244	EPSON	LQ 1170C		OK	
245	EPSON	LQ 1170C+		OK	
246	EPSON	LQ 2070C		OK	
247	EPSON	LQ 2080C		OK	
248	EPSON	LQ 2090		OK	
249	EPSON	LQ 2090C	OK	OK	OK
250	EPSON	LQ 2170C		OK	
251	EPSON	LQ 2180C		OK	
252	EPSON	LQ 2550		OK	
253	EPSON	LQ 300		OK	
254	EPSON	LQ 300+		OK	
255	EPSON	LQ 300+II	OK	OK	OK
256	EPSON	LQ 3500C		OK	
257	EPSON	LQ 570C		OK	
258	EPSON	LQ 570C+		OK	
259	EPSON	LQ 670		OK	

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
260	EPSON	LQ 670C		OK	
261	EPSON	LQ 680		OK	
262	EPSON	LQ 680C		OK	
263	EPSON	LQ 690C	OK	OK	OK
264	EPSON	MC-2000	OK		OK
265	EPSON	ME 320	OK		OK
266	EPSON	PictureMate PM250	OK		OK
267	EPSON	PLQ-20C	OK		OK
268	EPSON	PLQ-20CM	OK		OK
269	EPSON	PM-860PT	OK		OK
270	EPSON	PM-890C	OK		OK
271	EPSON	PM-920C	OK		OK
272	EPSON	PM-930C	OK		OK
273	EPSON	PM-950C	OK		OK
274	EPSON	PM-970C	OK		OK
275	EPSON	PM-980C	OK		OK
276	EPSON	PM-A550	OK		OK
277	EPSON	PM-A620	OK		OK
278	EPSON	PM-A650	OK		OK
279	EPSON	PM-A720	OK		OK
280	EPSON	PM-A820	OK		OK
281	EPSON	PM-A840	OK		OK
282	EPSON	PM-A850	OK		OK
283	EPSON	PM-A890	OK		OK
284	EPSON	PM-A900	OK		OK
285	EPSON	PM-A920	OK		OK
286	EPSON	PM-A940	OK		OK
287	EPSON	PM-A950	OK		OK
288	EPSON	PM-A970	OK		OK
289	EPSON	PM-2200C	OK		OK
290	EPSON	PM-3500C	OK		OK
291	EPSON	PM-3700C	OK		OK
292	EPSON	PM-4000PX	OK		OK
293	EPSON	PM-D800	OK		OK
294	EPSON	PM-D870	OK		OK
295	EPSON	PM-D1000	OK		OK
296	EPSON	PM-FA700	OK		OK
297	EPSON	PM-G800	OK		OK
298	EPSON	PM-G820	OK		OK
299	EPSON	PM-G850	OK		OK
300	EPSON	PM-G860	OK		OK
301	EPSON	PM-G4500	OK		OK
302	EPSON	PM-T960	OK		OK
303	EPSON	PM-T990	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
304	EPSON	PX-5000	OK		OK
305	EPSON	PX-A640	OK		OK
306	EPSON	PX-A740	OK		OK
307	EPSON	PX-G5300	OK		OK
308	EPSON	PX-G5100	OK		OK
309	EPSON	PX-G930	OK		OK
310	EPSON	PX-G5000	OK		OK
311	EPSON	PX-V780	OK		OK
312	EPSON	RX 510	OK		OK
313	EPSON	RX 530	OK		OK
314	EPSON	RX 590	OK		OK
315	EPSON	RX 630	OK		OK
316	EPSON	RX 690	OK		OK
317	EPSON	Stylus C110	OK		OK
318	EPSON	Stylus C20	OK		OK
319	EPSON	Stylus C40	OK		OK
320	EPSON	Stylus C41UX/SX	OK		OK
321	EPSON	Stylus C43UX	OK		OK
322	EPSON	Stylus C45	OK		OK
323	EPSON	Stylus C59	OK		OK
324	EPSON	Stylus C60	OK	OK	OK
325	EPSON	Stylus C63	OK	OK	OK
326	EPSON	Stylus C67	OK	OK	OK
327	EPSON	Stylus C79	OK		OK
328	EPSON	Stylus C83		OK	
329	EPSON	Stylus C90	OK		OK
330	EPSON	Stylus Color 1160	OK		OK
331	EPSON	Stylus Color 1500	OK		OK
332	EPSON	Stylus Color 1520	OK		OK
333	EPSON	Stylus Color 400		OK	
334	EPSON	Stylus Color 460			
335	EPSON	Stylus Color 600		OK	
336	EPSON	Stylus Color 640			
337	EPSON	Stylus Color 660			
338	EPSON	Stylus Color 670	OK	OK	OK
339	EPSON	Stylus Color 800	OK	OK	OK
340	EPSON	Stylus Color 810	OK	OK	OK
341	EPSON	Stylus Color 850	OK	OK	OK
342	EPSON	Stylus Color 900	OK		OK
343	EPSON	Stylus Color PRO 7600	OK	OK	OK
344	EPSON	Stylus CX-1500	OK		OK
345	EPSON	Stylus CX-2900	OK		OK
346	EPSON	Stylus CX-3500	OK		OK
347	EPSON	Stylus CX-3700	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
348	EPSON	Stylus CX-3900	OK		OK
349	EPSON	Stylus CX-4100	OK		OK
350	EPSON	Stylus CX-4700	OK		OK
351	EPSON	Stylus CX-4900	OK		OK
352	EPSON	Stylus CX-5300	OK		OK
353	EPSON	Stylus CX-5500	OK		OK
354	EPSON	Stylus CX-5505	OK		OK
355	EPSON	Stylus CX-5700F	OK		OK
356	EPSON	Stylus CX-5900	OK		OK
357	EPSON	Stylus CX-6900F	OK		OK
358	EPSON	Stylus CX-7300	OK		OK
359	EPSON	Stylus CX-7800	OK		OK
360	EPSON	Stylus CX-8300	OK		OK
361	EPSON	Stylus CX-9300F	OK		OK
362	EPSON	Stylus Office T30	OK		OK
363	EPSON	Stylus Office T40W	OK		OK
364	EPSON	Stylus Office TX300F	OK		OK
365	EPSON	Stylus Office TX510FN	OK		OK
366	EPSON	Stylus Office TX600FW	OK		OK
367	EPSON	Stylus Office TX610FW	OK		OK
368	EPSON	Stylus Office TX700W	OK		OK
369	EPSON	Stylus Office TX800FW	OK		OK
370	EPSON	Stylus Office T1100	OK		OK
371	EPSON	Stylus Photo 915	OK		OK
372	EPSON	Stylus Photo 1270	OK	OK	OK
373	EPSON	Stylus Photo 1290	OK		OK
374	EPSON	Stylus Photo 1390	OK		OK
375	EPSON	Stylus Photo 2100	OK		OK
376	EPSON	Stylus Photo 710	OK		OK
377	EPSON	Stylus Photo 720	OK		OK
378	EPSON	Stylus Photo 790	OK		OK
379	EPSON	Stylus Photo 810	OK	OK	OK
380	EPSON	Stylus Photo 830U	OK		OK
381	EPSON	Stylus Photo 900	OK	OK	OK
382	EPSON	Stylus Photo 915	OK		OK
383	EPSON	Stylus Photo EX2	OK	OK	OK
384	EPSON	Stylus Photo EX3	OK	OK	OK
385	EPSON	Stylus Photo R1800	OK	OK	OK
386	EPSON	Stylus Photo R1900	OK		OK
387	EPSON	Stylus Photo R210	OK		OK
388	EPSON	Stylus Photo R230	OK		OK
389	EPSON	Stylus Photo R250	OK		OK
390	EPSON	Stylus Photo R270	OK		OK
391	EPSON	Stylus Photo R310	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
392	EPSON	Stylus Photo R350	OK		OK
393	EPSON	Stylus Photo R2400	OK		OK
394	EPSON	Stylus Photo R290	OK		OK
395	EPSON	Stylus Photo R310	OK		OK
396	EPSON	Stylus Photo R350	OK		OK
397	EPSON	Stylus Photo R800	OK		OK
398	EPSON	Stylus Photo RX430	OK		OK
399	EPSON	Stylus Photo RX 510	OK		OK
400	EPSON	Stylus Photo RX 530	OK		OK
401	EPSON	Stylus Photo RX 590	OK		OK
402	EPSON	Stylus Photo RX 630	OK		OK
403	EPSON	Stylus Photo RX 650	OK		OK
404	EPSON	Stylus Photo RX 690	OK		OK
405	EPSON	Stylus Photo R2880	OK		OK
406	EPSON	Stylus Photo TX700W	OK		OK
407	EPSON	Stylus Photo TX600FW	OK		OK
408	EPSON	Stylus Photo TX800FW	OK		OK
409	EPSON	Stylus Pro 7600	OK	OK	OK
410	EPSON	Stylus PM-700C	OK		OK
411	EPSON	Stylus PRO 4000	OK		OK
412	EPSON	Stylus TX510FN	OK		OK
413	EPSON	Stylus TX610FW	OK		OK
414	EPSON	Stylus TX550W	OK		OK
415	EPSON	Stylus TX410	OK		OK
416	EPSON	Stylus TX420W	OK		OK
417	EPSON	Stylus TX200	OK		OK
418	EPSON	Stylus TX210	OK		OK
419	EPSON	Stylus TX220	OK		OK
420	EPSON	Stylus TX100	OK		OK
421	EPSON	Stylus TX110	OK		OK
422	EPSON	Stylus T20	OK		OK
423	EPSON	Stylus T21	OK		OK
424	EPSON	Stylus T22	OK		OK
425	EPSON	Stylus Photo T50	OK		OK
426	EPSON	T40W	OK		OK
427	EPSON	TM883 (III)		OK	
428	EPSON	TM-U210B			
429	EPSON	TM T88III		OK	
430	Canon	BJC-330		OK	
431	Canon	BJC-4200		OK	
432	Canon	BJC-4300		OK	
433	Canon	BJC-4500		OK	
434	Canon	BJC-4550		OK	
435	Canon	BJC-4600		OK	

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
436	Canon	BJC-620		OK	
437	Canon	BJF9000	OK		OK
438	Canon	D380	OK		OK
439	Canon	I-2355	OK		OK
440	Canon	I-255	OK		OK
441	Canon	I-320	OK		OK
442	Canon	I-355	OK		OK
443	Canon	I-450	OK		OK
444	Canon	I-455	OK		OK
445	Canon	I-470D	OK		OK
446	Canon	I-475D	OK		OK
447	Canon	I-550	OK		OK
448	Canon	I-560	OK		OK
449	Canon	I-850	OK		OK
450	Canon	I-865	OK		OK
451	Canon	I-950	OK		OK
452	Canon	I-6100	OK	OK	OK
453	Canon	I-6500	OK	OK	OK
454	Canon	I-850	OK		OK
455	Canon	I-865	OK		OK
456	Canon	I-905D	OK		OK
457	Canon	I-9100	OK		OK
458	Canon	I-950	OK		OK
459	Canon	I-9950	OK		OK
460	Canon	IP3680	OK		OK
461	Canon	IX4000	OK		OK
462	Canon	IX5000	OK		OK
463	Canon	Imageclass D380	OK		OK
464	Canon	MP-110	OK		OK
465	Canon	MP-130	OK		OK
466	Canon	MP 145	OK		OK
467	Canon	MP-150	OK		OK
468	Canon	MP-160	OK		OK
469	Canon	MP 180	OK		OK
470	Canon	MP-198	OK		OK
471	Canon	MP-258	OK		OK
472	Canon	MP-638	OK		OK
473	Canon	MP 730	OK		OK
474	Canon	MP 770	OK		OK
475	Canon	MP 780	OK		OK
476	Canon	MX318	OK		OK
477	Canon	MX320	OK		OK
478	Canon	MX357	OK		OK
479	Canon	MX700	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
480	Canon	PIXUS iP2500	OK		OK
481	Canon	PIXUS 990i	OK		OK
482	Canon	PIXMA iP1000	OK		OK
483	Canon	PIXMA iP1700	OK		OK
484	Canon	PIXMA iP1800	OK		OK
485	Canon	PIXMA iP1880	OK		OK
486	Canon	PIXMA iP1980	OK		OK
487	Canon	PIXMA iP2000	OK		OK
488	Canon	PIXMA iP3000	OK		OK
489	Canon	PIXMA iP3300	OK		OK
490	Canon	PIXMA iP3500	OK		OK
491	Canon	PIXMA iP3680	OK		OK
492	Canon	PIXMA iP4000	OK	OK	OK
493	Canon	PIXMA iP4200	OK		OK
494	Canon	PIXMA iP4300	OK		OK
495	Canon	PIXMA iP4500	OK		OK
496	Canon	PIXMA iP4680	OK		OK
497	Canon	PIXMA iP4760	OK		OK
498	Canon	PIXMA iP5000	OK		OK
499	Canon	PIXMA iP6000	OK		OK
500	Canon	PIXMA IP6000D	OK		OK
501	Canon	PIXMA iP8500	OK		OK
502	Canon	PIXMA MP110	OK		OK
503	Canon	PIXMA MP130	OK		OK
504	Canon	PIXMA MP145	OK		OK
505	Canon	PIXMA MP150	OK		OK
506	Canon	PIXMA MP160	OK		OK
507	Canon	PIXMA MP180	OK		OK
508	Canon	PIXMA MP450	OK		OK
509	Canon	PIXMA MP730	OK		OK
510	Canon	PIXMA MP780	OK		OK
511	Canon	PIXMA MP830	OK		OK
512	Canon	PIXMA MX320	OK		OK
513	Canon	PIXUS 990i	OK		OK
514	Canon	PIXUS MP770	OK		OK
515	Canon	PIXUS IP2500	OK		OK
516	Canon	S200 SRx	OK		OK
517	Canon	S400	OK		OK
518	Canon	S520	OK		OK
519	Canon	S-200SPX	OK		OK
520	Canon	S-520		OK	
521	Lexmark	C720		OK	
522	Lexmark	E230	OK		OK
523	Lexmark	E322	OK	OK	OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
524	Lexmark	Optra S1250		OK	
525	Lexmark	P4350	OK		OK
526	Lexmark	P6250	OK		OK
527	Lexmark	T420	OK	OK	OK
528	Lexmark	T620	OK	OK	OK
529	Lexmark	W812	OK	OK	OK
530	Lexmark	Z42	OK		OK
531	Lexmark	Z43	OK	OK	OK
532	Lexmark	Z45	OK		OK
533	Lexmark	Z55	OK	OK	OK
534	Lexmark	Z515	OK	OK	OK
535	Lexmark	Z615	OK		OK
536	Lexmark	Z705	OK	OK	OK
537	Star	NX-2420		OK	
538	Star	NX-2410		OK	
539	Brother	MFC 4800	OK	OK	OK
540	Brother	MFC 4800J	OK	OK	OK
541	Brother	MFC 6800	OK	OK	OK
542	Brother	MFC 7220	OK	OK	OK
543	Brother	MFC 7420	OK	OK	OK
544	Brother	MFC 7820N	OK	OK	OK
545	Brother	MFC 8840D	OK	OK	OK
546	Brother	MFC 210C	OK		OK
547	Brother	MFC 240C	OK		OK
548	Brother	HL1260		OK	
549	Brother	IntelliFax 2820	OK		OK
550	FUJI Xerox	Able 3321		OK	
551	FUJI Xerox	DL700		OK	
552	FUJI Xerox	DL900		OK	
553	FUJI Xerox	DL-3400		OK	
554	FUJI Xerox	DL-3800		OK	
555	FUJI Xerox	DL-3850		OK	
556	FUJI Xerox	DL-5800		OK	
557	FUJI Xerox	DL-6400Pro		OK	
558	FUJI Xerox	DL-6800		OK	
559	FUJI Xerox	DocuPrint 2050	OK	Ok	OK
560	FUJI Xerox	DocuPrint 240A	OK	OK	OK
561	FUJI Xerox	Docuprint C1110B	OK		OK
562	FUJI Xerox	FP 410		OK	
563	FUJI Xerox	Jet Wind 500C		OK	
564	FUJI Xerox	Phaser 3310	OK	OK	OK
565	FUJI Xerox	Phaser 3120		OK	
566	FUJI Xerox	WorkCentre3119	OK	OK	OK
567	FUJI Xerox	PP 10		OK	

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
568	Samsung	CLP-315	OK		OK
569	Samsung	CLP-500	OK	OK	OK
570	Samsung	CLP-510	OK	OK	OK
571	Samsung	CLX2160	OK		OK
572	Samsung	CLP-620ND	OK		OK
573	Samsung	ML-1250	OK	OK	OK
574	Samsung	ML-1510/1710	OK	OK	OK
575	Samsung	ML-1520	OK		OK
576	Samsung	ML-1660	OK		OK
577	Samsung	ML-1710	OK		OK
578	Samsung	ML-1750	OK	OK	OK
579	Samsung	ML-1915	OK		OK
580	Samsung	ML-2010	OK		OK
581	Samsung	ML-2250	OK	OK	OK
582	Samsung	ML-2550	OK	OK	OK
583	Samsung	ML-2580N	OK		OK
584	Samsung	ML-3471ND	OK	OK	OK
585	Samsung	SCX-4016	OK	OK	OK
586	Samsung	SCX-4200	OK		OK
587	Samsung	SCX-4100/4106/4116/4216F	OK	OK	OK
588	Samsung	SCX-4521F	OK	OK	OK
589	Samsung	SRP 270		OK	
590	Sharp	AR-255		OK	
591	Sharp	AR-265FG		OK	
592	Sharp	AR-5316	OK	OK	OK
593	Sharp	AR-M160		OK	
594	Sharp	AR-M185(AR-NB2)		OK	
595	Sharp	AR-M205		OK	
596	Sharp	AR-M207		OK	
597	Sharp	AR-M235		OK	
598	Sharp	AR-M275		OK	
599	Sharp	AR-M350		OK	
600	Sharp	AR-M351U		OK	
601	Sharp	AR-M400		OK	
602	Sharp	AR-M450		OK	
603	Konica Minolta	Di152		OK	
604	Konica Minolta	Di 200/Di 250/Di 251		OK	
605	Konica Minolta	magicolor 2450	OK	OK	OK
606	Konica Minolta	magicolor 5450	OK	OK	OK
607	Konica Minolta	magicolor 7300	OK		OK
608	Konica Minolta	Magicolor 7300	OK		OK
609	Konica Minolta	PagePro 1380MF	OK		OK
610	Konica Minolta	PagePro 1390MF	OK		OK
611	Konica Minolta	PagePro 9100	OK		OK

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
612	Panasonic	KX-P1121		OK	
613	Panasonic	KX-P1123		OK	
614	Panasonic	KX-P1124		OK	
615	Panasonic	KX-P1624		OK	
616	Panasonic	KX-P6500		OK	
617	IBM	Infoprint 20		OK	
618	IBM	Infoprint 1116	OK	OK	OK
619	IBM	Infoprint 1312	OK	OK	OK
620	IBM	Infoprint 1316	OK	OK	OK
621	IBM	Infoprint 1332	OK	OK	OK
622	IBM	Infoprint 1412	OK	OK	OK
623	NEC	NEC P2200		OK	
624	NEC	NEC P3200		OK	
625	NEC	NEC P5300		OK	
626	NEC	NEC P8000		OK	
627	Avison	MF 3200	OK		OK
628	Avison	MF 3230	OK		OK
629	DATAMAX	I-4208		OK	
630	DATAMAX	I-4308		OK	
631	DOCUJet	1610F	OK	OK	OK
632	DOCUJet	UA1610	OK	OK	OK
633	OKI	Microline 391		OK	
634	OKI	B4350	OK	OK	OK
635	OKI	OKI 5530		OK	
636	TOSHIBA	E-161	OK	OK	OK
637	TOSHIBA	Estudio-25		OK	
638	BENQ	CM3000	OK		OK
639	CityZen	GSX230		OK	
640	MITAC	MP-6600C		OK	
641	RICOH	NF3570		OK	
642	RICOH	AfcioMP1600	OK		OK
643	RICOH	MF1530		OK	
644	RICOH	imaggioMF2730		OK	
645	FUTEK	F8000		OK	
646	FUTEK	F70+		OK	
647	FUTEK	F80+		OK	
648	FUTEK	F8000		OK	
649	FUTEK	F84+		OK	
650	FUTEK	F90		OK	
651	FUTEK	F9000		OK	
652	FUTEK	F95		OK	
653	FUTEK	F96		OK	
654	FUTEK	F94		OK	
655	FUTEK	F93		OK	

No.	Manufacturer	Model	TL-PS110U	TL-PS110P	TL-WPS510U
656	FUTEK	F86+		OK	
657	Kyocera	FS-1010	OK	OK	OK
658	Kyocera	FS-1010KX		OK	
659	Kyocera	FS-1020/D	OK	OK	OK
660	Kyocera	FS-1030D	OK	OK	OK
661	Kyocera	FS-1920	OK	OK	OK
662	Kyocera	FS-2000D	OK	OK	OK
663	Kyocera	FS-820	OK	OK	OK
664	Kyocera	FS-920	OK	OK	OK
665	Kyocera	FS-6020	OK	OK	OK
666	Kyocera	FS-6026	OK	OK	OK
667	Kyocera	FS-820	OK	OK	OK
668	Kyocera	FS-920	OK	OK	OK
669	FUJITSU	DL3400		OK	
670	FUJITSU	DL3800		OK	
671	FUJITSU	DL3850		OK	
672	FUJITSU	DL6400		OK	
673	FUJITSU	DL6800		OK	
674	FUJITSU	DL5800		OK	
675	FUJITSU	DL700		OK	
676	FUJITSU	DL900		OK	
677	FUJITSU	PP10		OK	
678	FUJITSU	FP410		OK	
679	FUJITSU	DL5800		OK	