

Quick Installation Guide

TL-WA854RE

Method ONE: Quick Setup using the WPS Button

Method TWO: Setup using your Web Browser



LED Explanation

On: A secure connection has been established.

Flashing: TL-WA854RE is establishing a secure connection.

Off: No connection is active.

Wireless

Off: The wireless function of TL-WA854RE is disabled.

Flashing: The wireless function of

TL-WA854RE is enabled.

Power

On: TL-WA854RE is on



(Signal Strength)

Off: TL-WA854RE isn't connected to


On(1~5): TL-WA854RE is connected to the router. More LEDs indicate a better connection between TL-WA854RE and the router.

Method ONE

Quick Setup using the WPS Button


Use this if your router or AP supports WPS

Power on Plug your TL-WA854RE in near your router or AP.



Relocate

Once your TL-WA854RE is properly configured, you can move it to a more ideal location for optimal signal quality and range extension. Once placed in another power outlet, the extender will reconnect to the main router automatically in about 30 seconds. * Keep these in mind:



The ideal location for your extender is **Halfway** between your wireless router and Wi-Fi enabled devices.

minimum of 3 signal strength LEDs are lit.









Keep the extender as far away from devices like cordless phones, Bluetooth devices and microwave ovens as possible to minimize wireless frequency interference.

Try to place your extender **in open corridors or spacious locations** rather than a crowded room.




The TL-WA854RE shares the same Wi-Fi network name(SSID) and Wi-Fi password with your main router/AP.



FAQ(Frequently Asked Questions)

Q1. How to reset the TL-WA854RE?

Tip 1: Use a pin to press the RESET button on the bottom of the TL-WA854RE for 2 seconds while it is plugged into a power outlet. Wait 5 seconds until all of the TL-WR854RE's LEDs flash once. Tip 2: Log into the management page via your web browser, then go to "System Tools -> Factory Defaults" and click "Restore". Wait 5 seconds until all of the TL-WR854RE's LEDs flash once



Q2.1 typed http://tplinkextender.net in the browser URL bar, why can't I see the quick setup page?

Tip: First, make sure your computer is connected to the extender network and disconnected from any other network. Second, make sure your computer is set to obtain an IP address automatically

Q3. What's the technical support hotline?

 $\textbf{Tip:} Please \textit{visit} \ \textbf{www.tp-link.com} \ , \textit{find} \ \textbf{Support>} \textbf{Contact} \ \textbf{Technical Support>} \textbf{Hotline Support} \ \textit{for more information}. \ \textbf{Other forms of the forms of t$ support are also available on our website.

Setup using your Web Browser

Plug your TL-WA854RE in near your router or AP.

**Wait until the 'Wireless' LED starts flashing in about 15 seconds.

RE
Wireless**

Wireless

Power

Proved

Proved

Proved

Wireless

Power

Proved


2 Connect your computer to the TL-WA854RE

1 Disconnect your Ethernet Connection.
2 Click the Wireless Network Connection icon on your desktop.

3 Click the refresh icon 4 and connect to the TL-WA854RE (the default wireless network name is: TP-LINK_Extender_XXXXXXX) and continue to Step 3.

Configure via your Web Browser

1 Type in http://tplinkextender.net in your Web browser and press Enter. Log in management page using user name "admin" and password "admin".



It will take approximately 5 seconds or more until the above **login page pops up**.

If it still does not pop up even if you **refresh** the browser, please go to **the FAQ>> Q2.**

TP-LINK_Extender_XXXXXX

Connect automatically Connect

2 Below are the major steps of the setup process.



a. After logging in, you will see the **Quick Setup** page.




b. Select your router/AP's Wi-Fi network, for example, TP_LINK_XXX.



c. Fill in the **Wi-Fi Password of your main router/AP**. TL-WA854RE's **Wi-Fi network name (SSID)** can be copied from your main router/Al **(TP-LINK_XXX)** or be customized **(TP-LINK_XXX_EXT)**.



d. After completing the configuration, **check the LED lights**. Several (1 \sim 5) signal strength LEDs will light up if the configuration is successful.



4 Relocate



Flip this piece of paper. Step 4 is the same as Step 3 of **Method ONE**.



Choose TL-WA854RE 's **Wi-Fi** network name (TP-LINK_XXX or TP-LINK_XXX_EXT). The TL-WA854RE **shares** the **same Wi-Fi password** with your main router/AP.

