



This guide applies to:

EAP110 / EAP115 / EAP225 / EAP245 / EAP320 / EAP330 / EAP115-Wall / EAP225-Wall / EAP110-Outdoor / EAP225-Outdoor

As a stepping stone helping you get started in Omada EAPs, this article introduces how to choose an optimal management method in your situation, and the setup steps of each method.

Part 1: How to Select the Best Management Method for Your Needs

There are several essential considerations when looking for the optimal methods, from your network size to the management tools. This part helps you select the best management methods for your needs. For the detailed steps of each management method, refer to [Part 2: How to Manage EAPs with Different Management Methods](#).

Choose the Management Mode According to Your Wireless Network Size

Omada EAPs support two configuration modes: Controller Mode and Standalone Mode.

The following comparison chart clarifies the notable features of the two modes.

	Controller Mode	Standalone Mode
Feature	<ul style="list-style-type: none"> Recommended for managing mass EAPs in a large-scale wireless network Configure EAPs in batch 	<ul style="list-style-type: none"> Recommended for managing a small number of EAPs in a relatively small-sized wireless network. Configure EAPs singly
Pros	<ul style="list-style-type: none"> All features are available Configure EAPs at any place (with Cloud Access enabled) 	<ul style="list-style-type: none"> Easy to set up No extra software or device is required to be running
Cons	<ul style="list-style-type: none"> Omada Software Controller or OC200 must be installed and running 	<ul style="list-style-type: none"> Simple functions are available EAPs are accessible with environment limits

■ Controller Mode

Controller Mode is the preferred method for centrally managing mass EAPs in a large-scale wireless network. Controller Mode provides an all-in-one and super convenient solution for EAPs configurations and maintenance. With Cloud Access enabled, you can log in to the controller at any place. And you can view the AP devices, clients, statistics, insights, logs. Some advanced functions like customizing the facebook portal and monitoring the system topology on a map are only supported in Controller Mode, which are frequently used in a large-scale network.

In Controller Mode, all EAPs can be centrally configured and monitored via a software controller (Omada Software Controller) or a hardware controller (Omada Cloud Controller OC200). For how to determine the controller type, see [here](#) to get help.

■ Standalone Mode

Standalone Mode is designed for singly managing a small number of EAPs in a relatively small-sized wireless network. This mode is recommended for users who want to control their APs right away without taking the time to configure a controller, which can simplify the process.

In Standalone Mode, each EAP can be configured by the Omada app or the management web page. For detailed information about the configuration steps, see [here](#) to get help.

Choose Software Controller or OC200 According to Your Budget and Needs

Tailored to your needs and budget, choose an Omada Software Controller or an Omada Cloud Controller (OC200) to configure your EAPs in Controller Mode.

The following comparison chart clarifies the notable features of Software Controller and OC200.

Software Controller	Cloud Controller (OC200)
Similarity	
<ul style="list-style-type: none">• Configure EAPs in batches• Conduct real-time monitoring of EAPs locally or remotely through Omada Cloud service• Easily accessible through a web browser and the Omada app (iOS or Android)	
Difference	
<ul style="list-style-type: none">• Free to install and upgrade• Needs a reserved computer in your network to host if you use advanced functions• Recommended Maximum Number of APs is 500	<ul style="list-style-type: none">• Needs to be purchased additionally• Takes small space to deploy with slim body• Recommended Maximum Number of APs is 50 (Theoretical Maximum is 100)

■ Software Controller

Omada Software Controller is a free management software for TP-Link EAP devices. With this software hosted on the computer of your network, you can configure EAPs in batches and conduct real-time monitoring of EAPs locally or remotely through Omada Cloud service.

Omada Software Controller is required to be running for the devices to use advanced functions like Voucher portal. So the downside is additional considerations and expense for the computer's continuous work.

■ Cloud Controller (OC200)

The Omada Cloud Controller (OC200) is the management device which is pre-installed with the Omada Software Controller 3.0.2 or above. You just need to pay for the OC200, then the built-in Omada Controller software is free to use, no license fee or extra cost required. With the small size as a mobile phone which does not take much space, OC200 is easy to deploy and install.

Choose Omada App or a Web Browser According to Your Management Device

The suited management interface depends on what kind of management device you use.

■ Using a Web Browser

On a PC, you can use a web browser. Both Controller Mode and Standalone Mode support login with a web browser. In Controller Mode, the Mozilla Firefox, Google Chrome, Opera and Microsoft Internet are supported. We recommend that you use the latest version of browser to manage Omada Controller.

■ Using Omada App

On a mobile phone, you can use the Omada app. There are versions for iOS and Android, available for free on the App Store and Google Play. With Omada app, You can monitor your network or make quick configuration adjustments when you are on the go.

Part 2: How to Manage EAPs with Different Management Methods

Manage Your EAP via Omada App in Standalone Mode

Follow the steps to set up your EAP via Omada app in Standalone Mode.

1. Launch the Apple App Store (iOS) or Google Play store (Android) and search "TP-Link Omada" or simply scan the QR code to download and install the app.



2. Connect your mobile device to the EAP by using the SSID of the EAP (the default SSID is printed on the label at the bottom of the EAP in the format of **TP-Link 2.4GHz/5GHz_XXXXXX**).
3. Launch the Omada app, tap Standalone APs and wait for the EAP device to be discovered. Tap on the EAP device appearing on the page. Set a new username and password for your login account of the EAP.

Manage Your EAP via a Web Browser in Standalone Mode

Follow the steps to set up your EAPs via a web browser.

1. Connect wirelessly by using the SSID of the EAP (the default SSID is printed on the label at the bottom of the EAP in the format of **TP-Link 2.4GHz/5GHz_XXXXXX**).
2. Launch a web browser and enter **http://tplinkeap.net** in the address bar. Use **admin** for both Username and Password to log in.
3. Set up a new Username and Password for secure management purpose. Modify the wireless parameters and reconnect your wireless devices to the new wireless network.

Manage Your EAP Using Software Controller in Controller Mode

Follow the steps to set up your EAPs using Software Controller.

1. On the PC with Windows OS or Linux OS, download the Omada Controller installation file from TP-Link official website.
2. Run the file and follow the wizard to install the Omada Controller.
3. Launch the Omada Controller and follow the step-by-step instructions to complete the Quick Setup. After the wizard is finished, a login screen will appear.
4. Enter the username and password you created and click **Log in**. Then you can further configure the Omada Controller.

Manage Your EAP Using OC200 in Controller Mode

Follow the steps to set up your EAPs using OC200.

1. Deploy OC200 on your network and power it on. Make sure that your management device and OC200 are on the same subnet.
2. Check the DHCP server (typically a router) for OC200's IP address.
3. Launch a web browser and type OC200's IP address in the address bar, then press **Enter** (Windows) or **Return** (Mac).
4. Launch the OC200 and follow the step-by-step instructions to complete the configuration wizard.

Manage Your EAP with Omada Cloud Service in Controller Mode

1. Enable Cloud Access on the controller software or OC200.
2. Make sure that your management device and the controller (the OC200 device or the host installed with Omada Controller software) can access the internet.
3. Launch a web browser and type <https://omada.tplinkcloud.com> in the address bar, then press **Enter** (Windows) or **Return** (Mac). Enter your TP-Link ID and password to log in.
4. The configurations between the Software Controller and OC200 is are slightly different.

For Software Controller, a list of Omada Software Controller that has been bound with your TP-Link ID will appear. Click **Launch** to visit the web management interface of your controller software.

For OC200, enter your TP-Link ID and password to log in. Then click Add Cloud Controller and follow the instructions to add your OC200. Click Launch to visit the web management interface of OC200.

Manage Your EAP with Omada App in Controller Mode

First, you need to download Omada app on your mobile device from the the Apple App Store (iOS) or Google Play store (Android). Search "TP-Link Omada" or simply scan the QR code to download and install the app.



■ Local Access

For Software Controller, connect your mobile to the EAP by using the default SSID printed on the label of the EAP. Launch the app and go to **Local Access**, tap **+** button on the upper-right corner to add Omada controller.

For OC200, make sure that your management device and OC200 are on the same subnet. Launch the app and go to **Local Access**, tap **+** button on the upper-right corner to add OC200.

- **Remote Access**

For Software Controller, make sure that Cloud Access is enabled on your controller and your controller has been bound with a TP-Link ID. Launch the app and log in with your TP-Link ID. Then go to **Cloud Access**. A list of Omada Controller that has been bound with your TP-Link ID will appear. Then you can further configure the controller.

For OC200, make sure that your management device and OC200 can access the internet. Launch the app and log in with your TP-Link ID. Tap the **+** button on the upper-right corner to add OC200. Select OC200 and follow the step-by-step instructions to complete the configuration wizard.

Appendix: A Quick Overview of EAP Management Method

The following picture gives a quick overall information of the methods for managing Omada EAPs. You can scan the related QR code to open the corresponding configuration videos.

For more detailed introductions of the EAP and controller, you can visit <https://www.tp-link.com/support> to download the configuration guide in the download center. To ask questions, find answers, and communicate with TP-Link users or engineers, please visit <https://community.tp-link.com> to join TP-Link Community.

A Quick Overview of EAP Management Method



Scan the QR code to view the introduction video.

Controller Mode

Software Controller

- 1 On the PC with Windows OS or Linux OS, download the Omada Controller installation file from TP-Link official website.
- 2 Run the file and follow the wizard to install the Omada Controller.
- 3 Launch the Omada Controller and follow the step-by-step instructions to complete the Quick Setup. After the wizard is finished, a login screen will appear.
- 4 Enter the username and password you created and click Log in. Then you can further configure the Omada Controller.

Hardware Controller

- 1 Deploy OC200 on your network and power it on. Make sure that your management device and OC200 are on the same subnet.
- 2 Check the DHCP server (typically a router) for OC200's IP address.
- 3 Launch a web browser and type OC200's IP address in the address bar, the press **Enter**(Windows) or **Return**(Mac).
- 4 Launch the OC200 and follow the step-by-step instructions to complete the configuration wizard.



Scan the QR code to view the configuration video.

Standalone Mode

Omada App

- 1 Download Omada app on your mobile device.
- 2 Connect your mobile device to the EAP by using the SSID of the EAP (the default SSID is printed on the label at the bottom of the EAP).
- 3 Open the Omada app, and wait for the EAP device to appear on the Standalone APs page. Tap on the EAP device you want to configure.

Web Browser

- 1 Connect wirelessly by using the SSID of the EAP (the default SSID is printed on the label at the bottom of the EAP).
- 2 Launch a web browser and enter <http://tplinkeap.net> in the address bar. Use admin for both Username and Password to log in.
- 3 Set up a new Username and Password for secure management purpose. Modify the wireless parameters and reconnect your wireless devices to the new wireless network.



Scan the QR code to view the configuration video.

Using Omada Cloud Service in Controller Mode

Remote Management provided by free Omada Cloud Service.

- 1 Enable **Cloud Access** on the controller software (or OC200).
- 2 Make sure that your management device and the controller (the OC200 device or the host installed with Omada Controller software) can access the internet.
- 3 Launch a web browser and type <https://omada.tplinkcloud.com> in the address bar, then press **Enter** (Windows) or **Return** (Mac). Enter your TP-Link ID and password to log in.

4 For software Controller

A list of Omada Controller Software that has been bound with your TP-Link ID will appear. Click **Launch** to visit the web management interface of your controller software.



Scan the QR code to view the configuration video.

For OC200

Enter your TP-Link ID and password to log in. Then click **Add Cloud Controller** and follow the instructions to add your OC200. Click **Launch** to visit the web management interface of OC200.

Using Omada App in Controller Mode

Easy configuration in local or remote access provided by the Omada app.

- 1 Download Omada app on your mobile device.
- 2 **Local Access**
 - For software controller
Connect your mobile to the EAP by using the default SSID printed on the label of the EAP. Launch the app and go to **Local Access**, tap **+** button on the upper-right corner to add Omada controller.
 - For OC200
Make sure that your management device and OC200 are on the same subnet. Launch the app and go to **Local Access**, tap **+** button on the upper-right corner to add OC200.

Remote Access

- For software controller
Make sure that Cloud Access is enabled on your controller and your controller has been bound with a TP-Link ID. Launch the app and log in with your TP-Link ID. Then go to **Cloud Access**. A list of Omada Controller that has been bound with your TP-Link ID will appear. Then you can further configure the controller.
- For OC200
Make sure that your management device and OC200 can access the internet. Launch the app and log in with your TP-Link ID. Tap the **+** button on the upper-right corner to add OC200. Select OC200 and follow the step-by-step instructions to complete the configuration wizard.



Scan the QR code to view the configuration video.